

MTA CABLE MODEM

Connection Guide

1. Cable & Power



CABLE OUTLETS:
If 3-way multimedia outlets are not installed in your home, please use a TKS outlet adapter.


2. Computer

Ethernet (preferred)

-OR-


USB (driver installation required)

IMPORTANT: CHOOSE ONE CONNECTION CORD OR THE OTHER - DO NOT USE BOTH



3. Telephone

TEL 1: connect an analog phone here



TEL 2:
Only used with **TKS Cable Phone family** plan that has two phone lines, is **not active** with TKS Cable Phone eco.

Please consult your modem's user guide found on the CD-ROM for additional instructions.