

LevelOne Router WBR-3408

TKS QUICK INSTALLATION GUIDE

Getting started: connect the router to your computer
 Plug one end of the network cable into the **LAN 1** socket of the router, and the other end into your computer's **ETHERNET/LAN** port.

NOTE: For additional information concerning device connections, system, and power requirements, please refer to the manufacturer's original documentation.

1. Logon to the router

Launch your **Internet browser** (Internet Explorer, Firefox, etc.), click on the address box and delete all characters (the address box must be blank) type in: **192.168.0.1**

- Then press **Enter** on your keyboard.



Login Window

Type in the manufacture's default username/password, then click on **OK**.

USERNAME: admin
PASSWORD: password



2. Click **WAN Wizard** to proceed to initial setup.



3. Step through the Wizard until finished.

ISP Data

Carefully enter your TKSSurf! **username** and **password** when prompted, this information is found in your **TKSSurf! Access Package**.

TKS SERVICE	CONNECTION SETTING
TKSSurf! dsl	DSL / ADSL PPPoE
Cable Highseed (cable modem)	Cable Modem (TV Style)
All TKS services	IP always signed automatically (Dynamic IP Address)

4. On the final screen of the Wizard, run the test and check that an Internet connection can be established.

- If the connection fails, check your data, login account information, and the Cable/DSL modem.
- If your ISP has recorded your MAC (physical) address, change the MAC address (on the Wizard's Cable Modem screen) to match the value expected by your ISP.

To get online . . .

Launch your Internet browser and start surfing!

Wireless setup

To setup a secure wireless network connection, please refer to the detailed instructions outlined in the LevelOne user's manual found on the CD-ROM included with the device.